

USB to RS485 serial port pin module

I. Product Description

The function of the USB to TTL module is to convert the level to a signal that can be recognized by both parties for communication. The level logic of the microcontroller communication interface is different from that of the PC communication interface. The

Please read the product manual carefully before using the product.

communication interface on the PC has a USB interface, and the corresponding power level The level logic follows the USB principle. The serial communication on the

microcontroller passes through the four pins of RXD, TXD, VCC and GND of the microcontroller. The corresponding level logic follows the TTL principle. The USB to TTL serial port module is a very practical tool that can test the UART serial port communication of the module and download programs to the microcontroller through the UART interface of the microcontroller. The serial port assistant software on the computer can very intuitively display the data returned by the serial port device and send the corresponding control data to the serial port device. II. Specifications 1. A USB to TTL serial port communication module, suitable for microcontrollers and download line products.

3. TTL communication baud rate reaches 12Mbps, transmission speed is fast and stable, and full-duplex communication mode.

communication status.

4. The product has TTL3.3V and TTL5V level selection interfaces, and supports the access of handshake signals RTS and CTS. The communication is more stable and

2. Full-speed USB device interface design, compatible with USB V2.0/V1.1.

- supports output voltages of 3.3V and 5V for easy use. 5. The pin header design is used to facilitate the access and use of DuPont cable, and it has a signal indicator light for sending and receiving signals to control the
- 6. Circuit integrated ESD protection: ± 20 KV IEC1000-4-2 air gap discharge, ±15KV IEC1000-4-2 contact discharge. 7. The product is used for microcontroller program burning, chip communication information printing and other occasions, and is used by electronic engineers for
- 8. Support Win xp/Win7 and above/Mac 10.15 and above/Linux operating system.
- III. Interface Description

(6) (4) ② ①


Desktop compute

USB


Number


Ports and

other definitions



Illustrate





computer only scans a limited number of COM ports (e.g. 3 or 4) and therefore the computer does not recognize the COM5 port with this limitation until the COM port is

3. Data communication failed: Check whether the USB interface wiring is correct. Check whether the TTL output interface wiring is correct.

4. Data loss or error:

equipment are consistent.

through the official website.

1. Windows 2. MacOS

3. Android&Linux Driver

Ψ MS_USBSerial_windows_v1.0.2.11.1.exe 2023/8/24 17:52 Ψ MS_USBSerial_xp_v1.0.2.11.1.exe 2023/8/24 18:45

Check whether the terminal blocks are well connected.

reassigned.

Access
))) control system

Charging system

RS485/TTL

VII. MS series serial port line driver operation guide Scan the QR code included with the product to download and install the driver

Step 1: Download the driver installation package, click on the MS3020drive.zip

Check whether the data rates and formats at both ends of the data communication

compressed package, and decompress it. 类型 2023/8/29 11:35 360圧縮 ZIP 文件 67,559 KB MS3020drive.zip

Step 2: After decompression, as shown in the figure below, enter the Windows folder

文件夹

文件央

应用程序

类型

大小


大小

and double-click the application with the windows suffix.

Step 3: The installation dialog box pops up, click Next and Install until completed.

2023/8/29 13:43

修改日期



Win7 or Windows Server 2008 will pop up an unverifiable driver on some models. You need to manually click "Install this driver software anyway", as shown in the following figure: Windows Security

Step 5: Connect the product device to the computer and check whether the port

MacroSilicon USB Serial Ports (COM4) MacroSilicon USB Serial Ports (COM5)

Win7/Windows Server 2008 installation precautions

Windows can't verify the publisher of this driver software

Don't install this driver software You should check your manufacturer's website for updated driver software for your device.

➡ Install this driver software anyway Only install driver software obtained from your manufacturer's website or disc. Unsigned software from other sources may harm your computer or steal information.

If Win7 and Server2008 drivers still display signature errors (yellow marks), you need

windows6.1-kb4474419-v3-x64.msu, windows6.1-kb4490628-x64.msu, you need to

number is displayed in the device manager.

Network adapters Ports (COM & LPT)

Monitors

See details

to install two Win7 patches:

Model: Date of purchasel: User telephone: User address:

User telephone:



Distributor: Agency address:

Fault Treatment measures

Dealer stamp valid

Intenance Records Repair work NO.

Electronic products are guaranteed for one year, and other products are guaranteed for two years. Damage caused by human factors or product burnout caused by improper operation is not included in the scope of warranty.