Fiber Optic HDMI Cable ——User Manual——



This manual will help you install and use it.

Welcome!

1. Product Overview1.1 Safety PrecautionsAll safety instructions should be read and understood before the

Thank you for purchasing our product.

unit is operated. - The owner's manual and safety instructions should be retained

for future reference.

- Unplug this unit from the AV devices before cleaning.Do not use liquid or aerosol cleaners.Use a damp cloth only.
 Keep away from wet,magnetic,and flammable surfaces or subst
- -ances.Do not place any heavy objects or equipment on top of the unit.
- Home Classroom Commercial

 This product is easy to use, securely connected, and suitable

for any location where high-definition video displays, such as

home video distribution, conference room presentation systems, room projection systems, digital signage.

remote component locations.

Specifications

Supported features

Audio

1.2 Product Description

Fiber optics provides the speed and bandwidth needed for the best picture quality for high definition video; supporting the long

distances required in commercial video solutions.

 No extenders, balkans or amplifiers are needed free allowing them to be installed with multiple cable pulls, providing the flexibility for

- Data rate 18 Gbps

 Resolutions up to 4K@60Hz/fps(YUV 4:4:4)
- Supporting 18Gbps and 4K@6OHz performance.
 Designed to solve the installer's common problems with long distan -ce HDMI and concealed installations in home and business.

HDCP 2.2, EDID, CEC

3D, HDR, Deep Color

32 uncompressed Audio Channels; 1536 kHz

	Jacket diameter	4.8 mm				
	Cable sustained tension	30 pounds				
	Operating Temperature	32°—122°F (0°—50°C)				
	I. 3 Installation	e the installation procedure below. Imprope				
	or no operation may re collowed.	esult if the start-up sequence is not correctly				
 Carefully unpack the contents of the shipping group. Turn off the entire system before connecting. 						
ю	B00000***	<11>				

Plug directly the Tx (Source) connector of DTECH cable in the HDMI output port of your video source (DVD, Blu-ray,game console box, etc). Make sure cable is firmly inserted.

after-sales department

damage to the product.

cable is firmly inserted.

5. Turn power on the source and the display.

Note: Do not connect any intermediate cable or adapter between them as this may cause deterioration in signal Iransmission performance.

Non-professionals are not allowed to disassemble the casing to avoid

Computer Monitor

 Plug the Rx (Display) connector of DTECH cable to the HDMI input port of display (HDTV, LCD screen, Projector, etc). Make sure

When encountering product quality problems, first consult our

- Blu-ray Player HDTV
- 2. Troubleshooting 2.1 The display shows only black screen. -Ensure that the HDMI ports are firmly plugged in to the source and display. -Ensure that the Video source (Tx) is connected to the video source and Display (Rx) is connected to the display. -Check if the source and display are powered on and properly booted. -Re-boot up the system while connecting the optical HDMI extension module. 2.2 Screen is distorted or displays noises. -Check if the graphic resolution is properly set for the sources. For PCs, go to the display properties of OS and tap the settings. For other AV video source, refer to the owner's manual to adjust video resolution. -Reboot the system. Disconnect the optical HDMI cables if ne-

Customer Information

Model:

Date of purchasel:

Distributor

User telephone User address

Product Warranty Card

Agency add	ress								
User teleph	one:	Dealer stamp valid							
Intenance Records									
Repair times	Date	Fault	Treatment measures	Repair work NO					

Repair times	Date	Fault	Treatment measures	Repair work NO.